

## Smart-I Drive Mounting Bracket

### Quick Fix Guide

Please ensure that when removing the bracket you do not exert force upwards on the latch after it has been released.



In the unfortunate event that you have used too much pressure and the bracket has come apart you will need to follow the guide below.

The mounting bracket for the Smart-I Drive consists of the components below:



1. Suction Cup
2. Spring
3. Latch
4. Bracket

To assemble this bracket please see the steps below:

- First note the notch on the suction cup, this will be used to hold the latch in place.



- Place the spring on the centre part of the suction cup with the smaller end at the bottom as shown.

- Insert the suction cup and spring into the bottom of the bracket.



- Push up from the middle of the suction cup to ensure that the notches of it align with the notches on the bracket.



- Once the two notches are aligned you can insert the latch into the bracket.



- The mounting bracket is now assembled. You can attach it to a surface by pushing the suction cup down and lowering the latch.



*For more information on this product please see the SmartWitness web site at <http://www.smartwitness.com>.*

*If you require and further help or information please feel free to contact our technical support team or your point of purchase.*